



Part Code	Description	Qty
001	Socket Screw	2
002	Cross Recessed Pan Head Screw	6
003	Main Blade Holder	2
004	Locking Hexagon Nut	4
005	Bearing	4
006	Main Blade Washer	2
007	O-Shape Washer	2
008	Main Blade Screw	1
009	T-shape Main Axis Sleeve	1
010	Flybar	1
011	Flybar Paddle Holder	2

Part Code	Description	Qty
012	Flybar Washer	2
013	Flybar Screw	2
014	Flybar Paddle	2
015	Ball Linkage for Main Blade	2
016	Steering Linkage	9
017	Copper Sleeve 2	4
018	Bellcrank	2
019	Short Ball Link Rod	2
020	Aluminum Ball	11
021	Main Blade Holder (Lower)	2
022	Main Rotor Blade	2
023	Cross Recessed Trapping Pan Head Screw	22
024	Main Frame (L)	1
025	Canopy	1
026	Canopy Rod	1
027	Long Ball Link Rod	2
028	Type-1 Hexagon Nut	1
029	Main Shaft	1
030	Steering Dowel	1
031	Main Shaft Sleeve	1
032	L-shape Bellcrank	2
033	L-shape Ball Link	2
034	Washer	8
035	Cross Recessed Pan Head Screw	1
036	Balance Bar Sleeve	1
037	Steering Sleeve	1
038	Bearing	3
039	Cross Recessed Pan Head Screw	6
040	Principal Axis Steering (Sleeve/Upper)	1
041	Main Shaft Retaining Set (Sleeve/Lower)	1
042	Principal Axis Steering (Sleeve/Lower)	1
043	Thrust Bearing	2
044	Bearing	2
045	Swashplate	1
046	Steering Ball	1
047	Inner Shaft Rod sleeve	1
048	One-Way bearing	1
049	Steering Holder(Left)	1

Part Code	Description	Qty
050	Servo Pull Rod 1	1
051	Bearing	1
052	Main Gear	1
053	Reduction Gear	1
054	Motor Gear	1
055	Cross Recessed Pan Head Screw	2
056	Inner Shaft Rod	1
057	Battery	1
058	Cross Recessed Pan Head Screw	4
059	Motor	1
060	Ball Gear Sleeve	1
061	Ball Gear Shaft	1
062	Ball Gear Shaft Pin	3
063	Ball gear Retaining Ring	2
064	synchronous pulley	2
065	Double-Reduction Gear	1
066	Hexagon Socket Pin/Locking Screw	9
067	T-shape Shaft Sleeve	1
068	U-shape Connector	1
069	V-shape Connecting Rod	1
070	Cross Recessed Pan Head Screw	4
071	Casting Cap	4
072	Plain Washer (Class C)	7
073	Skid Landing	2
074	Skid Landing Gear	2
075	Receiver	1
076	Tail Servo Rod Holder	1
077	Tail Boom	1
078	Swashplate Control Handle	2
079	Detaching Holder (Right)	1
080	Tail Strut	2
081	Servo Pull Rod 2	1
082	9G-Servo-5	4
083	Servo Bellcrank	4
084	Trapping Screw with Washer	8
085	Main Frame (Right)	1
086	Ball Link Rod	1
087	Triangle Connector	1
088	Cross Recessed Pan Head Screw	2
089	Horizontal Stabilizer Holder	1
090	Horizontal Stabilizer	1
091	Tail Rotor Control Bellcrank	1

Part Code	Description	Qty
092	Vertical Stabilizer	1
093	Cross Recessed Pan Head Screw	4
094	Tail Rotor Holder (Lower)	1
095	Tail Rotor Ball Wheel	1
096	Step Bearing	2
097	Tail Rotor Holder (Upper)	1
098	Cylindrical Pin 4	1
099	Steering Copper Sleeve	1
100	Bearing	2
101	Tail rotor Sliding Sleeve	1
102	Tail Rotor Steering	1
103	Tail Rotor Blade	2
104	Cross Recessed Pan Head Screw	2
105	Tail Rotor Rotation Bellcrank	2
106	Tail Rotor Bellcrank	1
107	Tail Axis Connector	1
108	Bearing	3
109	Gyro	1
110	Cross Recessed Pan Head Screw	2
111	Ball Linkage	1
112	Copper Ball	1
113	Cross Recessed Pan Head Screw	9
114	Cross Recessed Pan Head Screw	8
115	Cross Recessed Pan Head Screw	4
116	Control Bellcrank Copper Sleeve	1
117	Triangle Bellcrank Bush	1
118	Cross Recessed Pan Head Screw	1
119	Toothed Synchronous Ball	2
120	Cylindrical Pin 5	2
121	Cross Recessed Pan Head Screw	2
122	Wire Holder	1
123	Ball Linkage	2
124	Tail Servo Linkages Shaft Washer	2
125	Tail Servo Holder	1
126	Tail Servo Pull Rod	1
127	Ball Link	5
128	Cross Recessed Pan Head Screw	13
129	Not Used	